

### Rear Tugger Application Chart

**Note: not all bikes are listed - we just can't measure all bikes out there. So...**

**If your bike has two rear seat mounting bolts, one on each side of the seat, get the Style 1.**

**If you have a KTM with the single under-seat bolt, get the Style 1 unless otherwise listed!**

**If you see your same model, but a different year, chances are good the style listed will work.**

**If you get one and it doesn't work, send it to us for a full refund.**

**If you are wondering about a FRONT Tugger, the Style 2 (Original or Extreme Enduro) works for all bikes.**

**If you are wondering about "Adjust length" column, it's just for us when we do custom embroidery.**

**The "Extra plastic spacers" are to space out the bushing so the buckle clears the recess in the plastic.**

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
<b>Beta</b>						
Beta	08	525	Style 1	12.0		
Beta	13-14	250RR	Style 1	16.5		
Beta	13-15	300RR	Style 1	16.5		
Beta	16	Xtrainer	Style 3-4			
Beta	18	300RR	Style 1	17.0		
<b>BMW</b>						
BMW	09	G450X	Style 1	9.0		
BMW	07	G650X	Style 1	13.5		
<b>Cannondale</b>						
Can	03	E440	Style 1	8.5		
<b>Cobra</b>						
Cobra	07	CX50JR	Style 3-4			
<b>GasGas</b>						
GAS	06	EC450	Style 1	10.0		
GAS	?	250	Style 1	10.0		
GAS	07-09	EC300	Style 1	10.0		
GAS	10-12	EC300	Style 1	16.0		
GAS	13	300RR	Style 1	16.0		
GAS		CAMI	Style 1	16.0		
GAS	18	XC300	Style 3-4			
<b>Honda</b>						
Hon	00	XR50	Style 3-4	6.5		
Hon	04-19	CRF50F	Style 3-4	6.5		
Hon		XR70	Style 1	10.5		
Hon	04-07	CR70F	Style 3-4	8.5		
Hon	00	XR80	Style 1	16"		
Hon	04-13	CRF80F	Style 3-4	9.3		
Hon	99	CR80R	Style 1	11.5		
Hon	03-05	CR85R	Style 1	11.3		
Hon	06	CR85R/RE	Style 1	9.0		
Hon	04-13	CRF100F	Style 3-4	9.3		
Hon	13-17	CRF110F	Style 1	10.5		
Hon	18	CRF110F	Style 1	10.5		use M6x30 bolt, 3 plastic washers, stock spacer
Hon	96	XR100	Style 1	14.0		
Hon	03	XR100	Style 3-4			
Hon	97	CR125R	Style 1	11.0		
Hon	00	CR125R	Style 1	10.5		
Hon	02-03	CR125R	Style 1	11.0		
Hon	04-06	CR125R	Style 1	10.9		
Hon	15-18	CRF125F/FB	Style 3-4			Mount under seat; sandwich between seat and frame
Hon	04-15	CRF150F	Style 3-4	10.5		

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Hon	07-13	CRF150R	Style 1	12.0		
Hon	2001	XR200R	Style 3-4			
Hon	04-15	CRF230F	Style 3-4			
Hon	19	CRF230F	Style 3-4			
Hon	09	CRF230M	Style 1	15.0		street bike version
Hon	09	CRF230L	Style 1	15.0		street bike version
Hon	13-16	CRF250L	Style 1	11.0		seat mount=11"; rear mount=8.5"
Hon	04-12	CRF250X	Style 1	10.3		
Hon	04-06	CRF250R	Style 1	9.8		
Hon	07	CRF250R	Style 1	11.2		
Hon	08-13	CRF250R	Style 1	10.0		
Hon	14-16	CRF250R	Style 1	9.0		Best to use two shoulder spacers on each side
Hon	94	CR250R	Style 1	11.0		
Hon	00-02	CR250R	Style 1	10.5		
Hon	03-04	CR250R	Style 1	11.0		
Hon	05-06	CR250R	Style 1	9.0		
Hon	03-04	XR250	Style 1	12.2	6	
Hon	01-04	XR400R	Style 1	12.2	6	
Hon	19	CRF450L	Style 1	11.0	2	M8x30 bolt, 3 plastic washers, 2 alum spacers each side
Hon	02-04	CRF450R	Style 1	11.0		
Hon	05-06	CRF450R	Style 1	9.8		
Hon	07	CRF450R	Style 1	10.8		
Hon	08-09	CRF450R	Style 1	10.0		
Hon	10-13	CRF450R	Style 1	9.0		
Hon	14-16	CRF450R	Style 1	9.0		Best to use two shoulder spacers on each side
Hon	17-18	CRF450R	Style 1	10.5		4 plastic & 1 alum spacer on each side, with M8x30 bolt
Hon	19	CRF450R	Style 1	10.5	4	M8x30 bolt, stock spacer, 3 or 4 plastic washers
Hon	17	CRF450RX	Style 1	10.5	4	4 plastic & 1 alum spacer on each side, with M8x30 bolt
Hon	05	CRF450X	Style 1	9.8		
Hon	06-16	CRF450X	Style 1	10.8		
Hon	95-00	CR500	Style 1	13.0		
Hon	01, 05	XR650R	Style 1	11.5	6	
Hon	05-15	XR650L	Style 1	18.0		
<b>Husaberg</b>						
Husa	06	FE550E	Style 1	12.0		
Husa	09	FE450	Style 1	12.0		
Husa	2013	FE350	Style 1	12.0		
<b>Husqvarna</b>						
Husq	17	TC50	Style 5			
Husq	18	TC50	--			No obvious solution
Husq	17	TC65	Style 5			
Husq	18	TC65	--			No obvious solution
Husq	15-17	TC85	Style 1	14.0		
Husq	18	TC85	Style 3-4			
Husq	06	CR125	Style 1	10.0		
Husq	17	TC125	Style 5		54	
Husq	19	TC125	Style 3-4			M6 x 12 bolt swages grommet to fit nicely
Husq	15	TE125	Style 1	14.0		Use a small aluminum spacer on each side
Husq	09	WR125	Style 1	12.0		
Husq	14	FC250	Style 1	14.0		Use a small aluminum spacer on each side
Husq	18	FC250	Style 5			
Husq	17	TE150	Style 5			

Make	Year	Model	Style	Adjust Tugger length to... inches	Extra plastic spacers?	Notes
Husq	16-18	FC250	Style 5			
Husq	17-18	FE250	Style 5			
Husq	06	TC250	Style 1	10.0		
Husq	10	TC250	Style 1	12.0		
Husq	16	TC250	Style 1	15.0		
Husq	17	TC250	Style 5			
Husq	19	TC250	Style 3-4			M6 x 12 bolt swages grommet to fit nicely
Husq	06	TE250	Style 1	10.0		
Husq	14	TE250	Style 1	12.0		Customer says same as '13 'Berg
Husq	17-18	TE250	Style 5			
Husq	19	TE250i	Style 5			
Husq	12	TCX250	Style 1	10.0		compatible with TC, TXC and WR with this body style - many years; just haven't measured them all
Husq	09	WR250	Style 1	12.0		
Husq	10	WR300	Style 1	12.0		
Husq	12-16	TE300	Style 1	14.0		
Husq	17	TE300	Style 5			
Husq	19	TE300i	Style 5			
Husq	18	TX300	Style 5			
Husq	19	TX300	Style 3-4			M6 x 12 bolt swages grommet to fit nicely
Husq	12	TE310	Style 1	12.0		
Husq	15	FC350	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16-18	FC350	Style 5			
Husq	15	FE350S	Style 1	14.0		Use a small aluminum spacer on each side
Husq	17	FE350	Style 5			
Husq	17-18	FE450	Style 5			
Husq	11	TE449	Style 1 special	27.0		special order - extra long Style 1
Husq	14	FC450	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16	FC450	Style 1	19.5		
Husq	17	FC450	Style 5			
Husq	18	FC450	Style 3-4			
Husq	19	FE450	Style 5			
Husq	18	FX450	Style 5			
Husq	19	FX450	Style 3-4			M6 x 12 bolt swages grommet to fit nicely
Husq	06	TC450	Style 1	10.0		
Husq	05	TE450	Style 1	10.0		
Husq	15	FE501/501S	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16	FE501	Style 1	14.0		
Husq	17	FE501	Style 5			
Husq	06	TC510	Style 1	10.0		
Husq	08	TE510	Style 1	10.0		
Husq	10	510TC, 510TE	Style 1	12.0		
Husq	08	TE610	Style 1	11.0		
Husq	16	Enduro 701	Style 1	17.0		
<b>Kawasaki</b>						
Kaw	06	KDX50	Style 1			
Kaw	07	KDX50	Style 3-4			
Kaw	04-'09	KX65	Style 1	11.0		
Kaw	16	KX65	Style 1	12.0		
Kaw	18	KX65	Style 1	12.0	8	Need longer bolt: M6 x 25
Kaw	04-'07	KX85	Style 1	13.5	4	
Kaw	08-09	KX85	Style 1	13.0	4	
Kaw	12	KX85	Style 1	11.0	4	

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Kaw	13-16	KX85	Style 1	13.5	6	
Kaw	19	KX85	Style 1	13.0	16	Need longer bolt: M6 x 35
Kaw	04-'17	KX100	Style 1	13.0	4	
Kaw	14-'16	KX100	Style 1	14.5	4	
Kaw	17-18	KX100	Style 1	18.0	10	Need longer bolt: M6 x 30
Kaw	04-13	KLX110, KLX110L	Style 1	11.0	6	Need longer bolt: M6 x 30
Kaw	14-19	KLX110, KLX110L	Style 1	13.0	10	Need longer bolt: M6 x 30
Kaw	04	KX125F	Style 1	11.1		
Kaw	04	KLX125	na	8.5		seat bracket style
Kaw	08-16	KLX140	Style 3-4	18.0		M8 is a tight fit through the grommet but it will work
Kaw	12-13	KLX140, 130L	Style 3-4	--		Must cut holes in plastic and feed Tugger through
Kaw	18-19	KLX140, 140L, 140G	Style 3-4	--		
Kaw	05	KDX200	Style 1	13.0		
Kaw	00-02	KDX220	Style 1	12.5	4	
Kaw	94	KDX250	Style 1	15.0	8	
Kaw	98	KX250	Style 1	9.8		
Kaw	01	KX250	Style 1	9.0		
Kaw	03-07	KX250	Style 1	11.5		
Kaw	04-18	KX250F	Style 1	11.5		
Kaw	04	KLR250	Style 1	17.0		
Kaw	06	KLX250	Style 1			
Kaw	07-09	KLX250S,SF	Style 1	12.0		
Kaw	98	KLX300R	Style 1	12.8		
Kaw	00	KLX300R	Style 1	12.8		
Kaw	04	KLX300R	Style 1	12.8		
Kaw	03	KLX400S	Style 1	11.0		
Kaw	08	KLX450R	Style 1	11.0		
Kaw	06-18	KX450F	Style 1	11.5		
Kaw	19	KX450	Style 1	9.5		
Kaw	00	KX500	Style 1	12.0		
Kaw	01	KX500	Style 1	14.5		
Kaw	04	KLR650	na			
<b>KTM</b>						
KTM	99-17	50 (all)	Style 3-4			
KTM	18-19	50SX	Style 3-4			May want to slot the plastic for the webbing to pass thru
KTM	02-14	65SX	Style 3-4			remove seat to install
KTM	17-18	65SX	Style 1	17.0		
KTM	19	65SX	Style 3-4			
KTM	08-09	65XC	Style 3-4			remove seat to install
KTM	02-12	85SX	Style 3-4			
KTM	13-17	85SX	Style 1	13.0		
KTM	08	85XC	Style 3-4	11.0		open end version
KTM	06-09	105SX	Style 3-4	12.0		remove fender to install
KTM	08	105XC	Style 3-4	11.0		remove fender to install
KTM	02-03	125SX	Style 1			
KTM	04-06	125SX	Style 3-4			
KTM	07-13	125SX	Style 1	15.0		
KTM	17	125SX	Style 1	17.5		
KTM	07-08	144SX	Style 1	15.0		

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
KTM	09	150SX	Style 1	15.0		
KTM	12-14	150SX	Style 1	14.0		
KTM	17-18	150SX	Style 1	18.0		
KTM	19	150SX	Style 1	22.0		
KTM	10-11	150XC	Style 1	15.0		
KTM	12-14	150XC	Style 1	14.0		
KTM	18-19	150XC-W	Style 1	18.0		
KTM	01-03	200EXC	Style 1	10.5		
KTM	04-06	200EXC	Style 1	12.8		
KTM	04-05	200SX	Style 3-4			
KTM	06	200 XC-W	Style 1			
KTM	06-07	200 XC	Style 1	13.0		
KTM	08-11	200 XC, XC-W	Style 1	15.0		
KTM	12-15	200 XC, XC-W	Style 1	14.0		
KTM	15	250 Freeride	Style 1	21"		
KTM	17	250 Freeride	Style 1	21"		
KTM	01	250EXC	Style 1	10.5		
KTM	04-06	250EXC	Style 1	12.8		
KTM	08	250EXC	Style 1	15.0		
KTM	18	250EXC-F	Style 1	18.0		
KTM	03-06	250SX	Style 3-4			
KTM	07-11	250SX	Style 1	15.0		
KTM	12-16	250SX	Style 1	14.0		
KTM	19	250SX	Style 1	22.0		
KTM	06	250SXF	Style 3-4	13.0		NO tapped holes in subframe stubs; can't use Style 1
KTM	07-11	250SXF	Style 1	15.0		
KTM	12-15	250SXF	Style 1	14.0		
KTM	16-18	250 SX-F	Style 1	18.0		
KTM	19	250 SX-F	Style 1	22.0		
KTM	08-11	250XC	Style 1	15.0		
KTM	12-14	250XC	Style 1	14.0		
KTM	18	250XC	Style 1	18.0		
KTM	19	250XC	Style 1	22.0		
KTM	07-11	250XC-F	Style 1	15.0		
KTM	12-14	250XC-F	Style 1	14.0		
KTM	17	250XC-F	Style 1	17.5		
KTM	19	250XC-F	Style 1	22.0		
KTM	07	250XCF-W	Style 1	12.0		
KTM	08-11	250XCF-W	Style 1	15.0		
KTM	12-15	250XCF-W	Style 1	14.0		
KTM	07-11	250XC-W	Style 1	15.0		
KTM	12-16	250XC-W	Style 1	14.0		
KTM	17-19	250XC-W	Style 1	18.0		
KTM	04-06	300MXC	Style 1	13.0		
KTM	04-06	300EXC	Style 1	13.0		
KTM	08	300EXC	Style 1	15.0		
KTM	06-07	300XC	Style 1	12.8		
KTM	08-11	300XC	Style 1	15.0		
KTM	12-16	300XC	Style 1	14.0		
KTM	17-18	300XC	Style 1	18.0		
KTM	19	300XC	Style 1	22.0		
KTM	06-07	300XC-W	Style 1	12.8		
KTM	09-11	300XC-W	Style 1	15.0		

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
KTM	12-16	300XC-W	Style 1	14.0		
KTM	17-19	300XC-W	Style 1	18.0		
KTM	11	350 (all)	Style 1	15.0		
KTM	12-15	350 (all)	Style 1	14.0		
KTM	16	350 XCF-W	Style 1	14.0		
KTM	16	350 EXC-F	Style 1	14.0		
KTM	18	350 EXC-F	Style 1	18.0		
KTM	16-18	350 SX-F	Style 1	18.0		
KTM	19	350 SX-F	Style 1	22.0		
KTM	16-18	350 XC-F	Style 1	18.0		
KTM	19	350 XC-F	Style 1	22.0		
KTM	99	380EXC	Style 1	11.0		
KTM	01	400SX	Style 1	10.5		
KTM	01-02	400E/MXC	Style 1	10.5		
KTM	03-06	450SX	Style 3-4			
KTM	07-11	450SXF	Style 1	15.0		
KTM	03	450EXC	Style 1	10.5		
KTM	18	450EXC-F	Style 1	18.0		
KTM	04-07	450 (all)	Style 1	14.0		
KTM	08-11	450 (all)	Style 1	15.0		
KTM	12-15	450 (all)	Style 1	14.0		
KTM	16	450 XC-W	Style 1	14.0		
KTM	17-18	450 XC-F	Style 1	18.0		
KTM	19	450 XC-F	Style 1	22.0		
KTM	06-07	450SMR	Style 3-4	13.0		
KTM	12-16	500 (all)	Style 1	14.0		
KTM	18	500EXC-F	Style 1	18.0		
KTM	08-09	505XCF	Style 1	15.0		
KTM	02	520EXC	Style 1	10.5		
KTM	01	520EXC	Style 1	10.5		
KTM	04-05	525MXC	Style 1	14.0		
KTM	04-07	525EXC	Style 1	13.5		
KTM	07	525XC	Style 1	13.0		
KTM	06	525SX	Style 3-4	14.0		NO tapped holes in subframe stubs; can't use Style 1
KTM	08-11	530 (all)	Style 1	15.0		
KTM	06	560 SMR	Style 3-4			
KTM	96-04	LC4	Style 1	15.5"		
KTM	04	625 SXC	Style 1	15.5"		
KTM	02	LC4-640E	Style 1	18.5"		
KTM	06-07	All XC	Style 1	14.0		
KTM	06-07	All XC-W	Style 1	14.0		
KTM	09-16	690 Enduro	none			none available for this model
KTM	04	950 Adv	Style 1	18"	12	
<b>LEM</b>						
LEM	05	RX3	Style 1	10.0		
<b>Sherco</b>						
Sherco	2017	300 SE-R	Style 1	18.0		pics available
Sherco	05-08	450 enduro	Style 1			
Sherco	05-08	510 enduro	Style 1			
Sherco	18-19	125 to 500 SC & SE	Style 1	15.0		
<b>Suzuki</b>						

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Suz	07	JR50	Style 3-4			
Suz	03, 04	RM65	Style 1	10.8	12	
Suz	19	DRZ50	Style 3-4			
Suz	08-18	DRZ70	Style 3-4			With M8 bolts it's a tight fit but will work
Suz	04	RM80	Style 1	10.4		
Suz	07-18	RM85	Style 1	11.0		
Suz	04	DRZ110	Style 1	10.8		
Suz	04	DRZ125	na	8.8		seat bracket style
Suz	04-06	DRZ125L	na			seat bracket style
Suz	07	DRZ125L	Style 3-4			
Suz	08-18	DRZ125L	Style 1	10.0		
Suz	04	RM125	Style 1	10.3		
Suz	06	RM125	Style 1	10.0		
Suz	15-16	DR200S	Style 1	16.0		
Suz	98	RM250	Style 1	10.3		
Suz	00	RM250	Style 1	10.3		
Suz	04-08	RM250	Style 1	10.5		
Suz	04-18	RMZ250	Style 1	11.0	4	
Suz	07	DRZ250	na	na		
Suz	01	DRZ400S	Style 1	11.0	2	
Suz	04-07	DRZ400S	Style 1	11.0	2	
Suz	00-04	DRZ400E	Style 1	10.5		
Suz	09	DRZ400	Style 1	11.0		
Suz	09-16	DRZ400SM	Style 1	11.0		Could also mount to brackets farther back than the seat - 15" in that case
Suz	09	DRZ400Dual	Style 1	11.0		
Suz	17-18	RMX450Z	Style 1	11.0	2	
Suz	06-11	RMZ450	Style 1	11.0		
Suz	12-17	RMZ450	Style 1	12.5		
Suz	18	RMZ450	Style 1	10.5		
Suz		DR650	Style 1	15.0		
<b>TM</b>						
TM	00	300 EN	Style 1	10.0		
TM	07-09	250 enduro	Style 1	14.5		
TM	15	85MX	Style 1	11.0		
<b>Yamaha</b>						
Yam	08-17	PW50	Style 3-4			
Yam	05-17	TTR50	Style 3-4			
Yam	81	PW80	Style 1			
Yam	04-06	PW80	Style 3-4			
Yam	04-15	YZ85	Style 1	10.5		
Yam	04	TTR90	Style 3-4			
Yam	08	TTR110	Style 1	12.0		
Yam	09	TTR110	Style 3-4			
Yam	12	TTR110	Style 1	12.0		
Yam	16-18	TTR110	Style 3-4			
Yam	01-07	TTR125, TTR125L	Style 1	10.5	6	
Yam	08-12	TTR125, TTR125L	Style 1	11.0	6	
Yam	13-18	TTR125, TTR125L	Style 1	11.0	6	Right side mounts under plastic; left side needs 8 plastic spacers and M8x35 bolt

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Yam	19	TTR125, TTR125L	Style 3-4			
Yam	00-01	YZ125	Style 1	8.8	4	
Yam	02-07	YZ125	Style 1	10.5	4	
Yam	09	TW200	Style 3-4			Need to double check if M6 or M8 bolts
Yam	04	XT225	Style 1	14.3		
Yam	04	TTR225	Style 1	15.5		frame has M8 threaded holes to use
Yam	06-17	TTR230	Style 1	9.5		
Yam	05	TTR250	3-4 special			Special, longer style 3-4; 28" 'tween grommets
Yam	02-06	WR250F	Style 1	9.5		
Yam	07-12	WR250F	Style 1	10.5		
Yam	15-16	WR250F	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	08-09	WR250R	Style 3-4			street legal; uses two seat mounting bolts underneath
Yam	12	WR250R	N/A			Customer reports neither Style 1 nor Style 3-4 work
Yam	14-16	WR250R	Style 3-4			Customer very happy - see pics
Yam	08-09	WR250X	Style 3-4			need to trim the plastic a bit
Yam	96	YZ250	Style 1	10.0	6	
Yam	99	YZ250	Style 1	9.0	6	
Yam	01	YZ250	Style 1	8.5	4	
Yam	02-06	YZ250	Style 1	10.0	4	
Yam	17	YZ250	Style 1	10.5		
Yam	01-12	YZ250F	Style 1	10.0		
Yam	13-18	YZ250F	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	19	YZ250F	Style 1	9.5		
Yam	15	YZ250FX	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	09	XT250	Style 1	11.0		replaces existing handles - have to trim the plastic a bit
Yam	98	YZ400F	Style 1	8.6		
Yam	01	WR426F	Style 1	8.8		
Yam	02	YZ426F	Style 1	8.6		
Yam	04-06	YZ450F	Style 1	9.1		
Yam	08-12	YZ450F	Style 1	10.0		
Yam	13-17	YZ450F	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	18	YZ450F	Style 1	9.0		
Yam	19	YZ450F	Style 1	9.5		
Yam	18	YZ450FX	Style 1	10.5	6	Need to use longer M8 bolts - M8 x 30
Yam	19	YZ450FX	Style 1	9.5		
Yam	04-07	WR450F	Style 1	9.1		
Yam	08-17	WR450F	Style 1	10.5		
Yam	84	IT490	Style 1	20.5		
Yam	92	WR500	Style 1	17.2	6	